



Installation Advice

Thank you for choosing the Rika Block™ for your project, here are some tips on how to properly utilise the Rika Block™ for maximum effectiveness:

DO:

- Make sure the ground that will be under the Rika Block™ is level and correctly compacted.
- Should the ground be at a gradient make sure that the area under the Rika Block™ is level.
- The use of gravel is highly recommended on especially on sandy soil to reduce shifting and water build up.
- Use the correct size timber in the correct slot on the Rika Block™ ie: 38mm timber goes in the 'thinner' slot and 50mm timber goes in the 'thicker' slot.
- Please use a grinder to reduce the size of the timber should you find the timber is slightly too thick.
- Make sure the timber is seated in the base of the mould.

DO NOT:

- Force timber into the Rika Block™.
- Use a hammer or mishandle the product as it will chip and break.

Should you wish to see an instructional video please go have a look at our videos on YouTube or Facebook.